



BEDIENUNGSANLEITUNG | USER MANUAL INSTRUKCJA OBSŁUGI

**OMS 138 PRO-TR
OMS 1316 PRO-TR
OMS 1324 PRO-TR
OMS 1332 PRO-TR**

**OMS 178 PRO-TR
OMS 1716 PRO-TR
OMS 1724 PRO-TR
OMS 1732 PRO-TR**



INFO ON THE SAYETY AND ASSEMBLY

The MS serves for the distribution of satellite and terrestrial TV and radio programs in the private sector. Observe all information in this manual. Any other use is considered improper and may result in property damage or personal injury. There is no liability for damages caused by improper use.



Info on the sayety and assembly

- Assembly and servicing should be carried out by electricians.
- Check the system for short circuits in the coaxial cables before starting up.
- Only install the system when it is not connected to the mains supply (230V).
- Mount the multiswitch...
 - on a non-flammable background (wall),
 - in a dust-free, dry environment,
 - in such a manner that it is protected from moisture, fumes,
 - splashing water and dampness,
 - somewhere protected from direct sunlight,
 - not within the immediate vicinity of heat sources,
- Make sure the input levels of the SAT stages are as equal as possible.
- Beware of short circuits!
- No liability is accepted for any damage caused by faulty connections
- or inappropriate handling.
- Observe the relevant standards, regulations and guidelines on the
- installation and operation of antenna systems.



Norms and standards

With the CE mark, the manufacturer declares that the product complies with the essential requirements and guidelines of the European regulations. These can be requested. All trademarks and registered trademarks are the property of their respective owners.



Protection insulation

This device has protection class II.
The power supply is double and high insulated.



Place for mounting

Use only dry rooms. This product is only designed for indoor use and should not come into contact with water or dust. To prevent overheating the power supply should not be covered when it is in use. The ambient temperature must not exceed 55 ° C. Only mount on a fire-proof area.



Grounding and equipotential bonding


In accordance with EN 50083-1 / VDE 0855, the local safety regulations must be observed when installing a satellite reception system.




Disposal

Electronic equipment is not domestic waste - it must be disposed of properly in accordance with directive 2002/96/EC OF THE EUROPEAN PARLIAMENT AND THE COUNCIL dated 27th January 2003 concerning used electrical and electronic appliances. At the end of its service life, take this device for disposal at a designated public collection point.


CONNECTION EXPLANATION ON MULTISWITCH


- A** **1 2** RECEIVER OUTPUTS
- B** **12V** POWER SUPPLY
- C**
 - H** HIGH-BAND LNC INPUT: H HIGH-BAND (17V / 22 kHz)
 - V** HIGH-BAND LNC INPUT: V HIGH-BAND (13V / 22 kHz)
 - H** LOW-BAND LNC INPUT: H LOW-BAND (17V / 0 kHz)
 - V** LOW-BAND LNC INPUT: V LOW-BAND (13V / 0 kHz)
- D** **TERR** TERRESTRIC INPUT (UKW/DAB+/DVB-T2)
- E** **0db -15db** TERRESTRIC REGULATOR (0 db -15 dB)
- F**  GROUND

CONNECTION ON MULTISWITCH OMS 138 PRO-TR



CONNECTION ON MULTISWITCH OMS 1724 PRO-TR





RED

OPTICUM[®]

PRODUCER/HERSTELLER:
AX TECHNOLOGY Sp. z o.o. Sp.k.
ul. Szczecińska 1W
72-003 Dobra, Poland
www.axtechnology.eu

